




JT-2QB 230V
 JT-1QB 120V
 JT-9QB 100V

HIGH POWER HOT-AIR STATION
 FROM SERIE -

SPARE PARTS	
JT-2B / JT-1B / JT-9B:	
-ENCLOSURES:	
·TOP	0011035
·BOTTOM	0009772
·FRONT	0010064
·BACK	0012672
-FRONT CIRCUIT	0011524
JT-2B:	
-TOP CIRCUIT	0011521
-SUCTION PUMP	0008938
-HOT AIR PUMP	0012273
JT-1B / JT-9B:	
-TOP CIRCUIT	0011523
-SUCTION PUMP	0008940
-HOT AIR PUMP	0012272

JT-2B 230V FUSE T-4A
 JT-1B 120V FUSE T-8A
 JT-9B 100V FUSE T-8A

JT-2B / JT-1B / JT-9B



0009829

0011070 (230V)
 0007565 (100V, 120V)

JT-T2A (230V)
 JT-T1A (100V, 120V)

JN2020

JN2012

JN2015